

# ИНСТРУКЦИЯ ПО МОНТАЖУ ABBER Schwarzer Diamant


AG30100B/AG30110B/AG30120B/AG30130B/AG30140B/AG30150B/  
AG30160B/AG30170B

## НЕОБХОДИМЫЕ ИНСТРУМЕНТЫ



## СПИСОК ДЕТАЛЕЙ

X2	X1	X1	X2	X2	X2	X2
X2	X1	X2	X1	X1	X2	X8
X16	X4	X2	X2	X4	Ф3.2 X1	



1

РАЗМЕР	A (ММ)
1000	990-1020
1100	1090-1120
1200	1190-1220
1300	1290-1320
1600	1590-1620
1700	1690-1720

2

3

4

5

6

